



Atlas Copco

QAS+ 450 Sd S5

| | |
|-----------------------|------------------------|
| Engine / Alternator | DC13 / LSA47.2S5 |
| Fuel tank capacity | 1240 L |
| Oil system capacity | 45 L |
| Cool. system capacity | 35 L |
| Urea Tank Capacity | 63 L (70L 1st filling) |



Service Pak

| Description | Order Nr |
|-------------------|--------------|
| SERVICE PAK 500H | 1636 3108 83 |
| SERVICE PAK 1000H | 1636 3108 84 |
| SERVICE PAK 2000H | 1636 3108 86 |



Engine Parts

| | |
|-------------------------|--------------|
| ROCKER C. GASKET UP. | 2914 8856 00 |
| ROCKER C. GASKET LOW. | 2914 8857 00 |
| ENG. OIL FILLER CAP | 1028 9006 55 |
| ENG. OIL DIPSTICK | 1636 3044 55 |
| AIR COOLER | 1640 0059 30 |
| RADIATOR | 1640 0059 40 |
| FAN MOTOR | 1640 0015 70 |
| FAN | 1640 0169 50 |
| MOTOR (2ND COOL. SYST.) | 1636 0218 42 |
| OIL DRAIN PUMP | 1626 0469 00 |
| THERMOSTAT | 1636 3038 95 |
| THERMOSTAT GASKET | 1636 3038 96 |
| COOLANT LEVEL INDICAT. | 1636 0252 47 |
| OIL PRESSURE SENSOR | 1636 3039 20 |
| FUEL COMBINED SENSOR | 1636 3044 91 |
| FRONT COVER SEAL | 1636 3044 67 |
| REAR SEAL | 1636 3044 68 |
| SHUT-OFF VALVE (WS FIL) | 1636 3039 16 |
| AIR PRESSURE SENSOR | 1640 0059 20 |
| COOLANT PUMP | 1636 3044 64 |
| TURBOCHARGER | 1636 3044 61 |
| OIL PUMP | 1636 3044 57 |
| FUEL HEATER | 1636 3039 13 |
| CHARGING ALTERNATOR | 2914 8882 00 |
| STARTER MOTOR | 1028 8632 00 |
| ALT. BELT | 1028 8536 13 |
| OIL FILTER KIT | 2913 0000 10 |
| FUEL FILTERS KIT | 2913 0000 30 |
| CENTR. OIL FILTER ELEM. | 2914 5109 00 |
| AIR FILTER ELEMENT | 2914 5077 00 |
| SAFETY CARTRIDGE | 2914 5018 00 |
| TANK BREATHER FILTER | 2914 9975 00 |



Fluids

| Description | Order Nr |
|-----------------------------------|--------------|
| PAROIL E MISS. GREEN 5L (1.32GAL) | 1630 0471 00 |
| PAROIL E MISS. GREEN 20L (5.2GAL) | 1630 0472 00 |
| PAROIL E XTRA 5L (1.32GAL) | 1630 0135 01 |
| PAROIL E XTRA 20L (5.28GAL) | 1630 0136 01 |
| PARCOOL GREEN 5L (1.32GAL) | 1604 8159 01 |
| PARCOOL GREEN 20L (5.28GAL) | 1604 5307 02 |



Alternator Parts

| Description | Order Nr |
|----------------------|--------------|
| INTERFACE SUPPRESSOR | 1636 3031 01 |
| FAN | 1636 3031 05 |
| DIODE BRIDGE | 2914 8409 00 |
| VARISTOR | 2914 8410 00 |
| REAR BEARING KIT | 1636 3104 80 |
| AVR D350 | 1636 3039 83 |
| NFLINK INTERFACE | 1636 3040 24 |
| VIBRATION DUMPER | 1640 0012 30 |



Keys

| Description | Order Nr |
|------------------------|--------------|
| FUEL TANK CAP | 1636 0000 15 |
| UREA TANK CAP | 1636 0373 78 |
| FUEL/UREA TANK CAP KEY | 2914 9500 00 |
| DOOR KEYS | 1615 7271 00 |



After-Treatment

| Description | Order Nr |
|--------------------------|--------------|
| KIT FILTER SCR RED. PUMP | 2914 8875 00 |
| FILTER ASSY SCR TANK | 2914 8878 00 |
| FILLER CAP FILTER | 1636 0249 86 |
| REDUCTANT PICK-UP UNIT | 1636 3044 72 |
| REDUCT. PICK-UP ORING | 1636 3044 74 |
| DIFF. PRESSURE SENSOR | 1636 3044 78 |
| NOX SENSOR | 1636 3044 85 |