Power Focus XC

Printed Matter No. 9839 2474 01 Publication Date 2021-07-02

Valid from Serial No. -

Instruction Supplement

Power Focus XC 8436180050



MARNING



To reduce risk of injury, everyone using, installing, repairing, maintaining, changing accessories on, or working near this tool MUST read and understand these instructions before performing any such task.

DO NOT DISCARD - GIVE TO USER



Table of Contents


Instruction Supplement	. 3
Getting Started with Power Focus XC	. 3

EN

Instruction Supplement

Getting Started with Power Focus XC

There are two user interfaces available for the Power Focus XCPower Focus XC controller. This supplement describes how to choose and access the suitable user interface depending on your needs.



Mobile Interface

The mobile interface is suited for mobile devices, such as phones and tablets, and has a restricted functionality. This interface is intended to be used when working conditions do not allow the use of the web interface or when it is more convenient to use a mobile interface to work. This interface allows the use of these two tightening strategies: *Tighten to Torque* and *Tighten to Torque plus Angle*.

Accessing the mobile interface

- (i) Scanning a QR code requires either a mobile camera or a QR scanning app. If your mobile camera can't scan the code, download a QR scanning app.
- 1. On the front part of the controller, scan the QR code on the left (1).
- 2. Scan the QR code on the right side of the controller (2).

Working with the mobile interface

The GUI of this simplified interface has four tabs: Task, Controller, Results and Help.

- The **Task** tab contains the list of available programs.
 - Select the desired program to activate it.
 - To add a new program, select the **plus** icon in the upper-right corner of the screen. To modify programs, slide the **Edit** selector to **On** and tap the **ellipsis** icon on the program to be edited. Select **Apply** to save changes. Select **Undo** to discard changes.
- The **Controller** tab enables to export data.

There are two ways of exporting data:

- To Device to download the selected data to the mobile device.
- To USB to download the selected data to a correctly formatted USB storage device connected to the USB port on the front part of the controller.

The available information to export is: All controller information, Settings and configurations, Logs from connected tools and Results.

- (i) All controller information and Settings and configurations do not include information about the connected tools.
- (i) Settings and configurations only exports the settings and takes less time to perform.
- (i) For STB, SRB, and TBP tools, it is only possible to export logs.
 - When **Logs from connected tools** is selected and no tools are connected to the controller, an empty file will be exported.
- (i) Results only exports tightening results from the controller.

Web Interface

The web interface is suited for computers and has an extensive functionality. This interface is suitable if you need complete access to all configurations of the controller.

Accessing the web interface

- 1. Connect one end of a straight-through unshielded Ethernet cable (RJ45) to a computer and the other end to the Ethernet cable connector (service port) on the controller (3).
- 2. Open a web browser on the computer and enter the web address shown under the Ethernet cable connector (service port) (4).



